

OUTSIDE

Buttons



On/Off

Press for start or pause
Press (5 sec) for turn on/off
Press together with Home (5 sec)
for WLAN connection

Home

Press to send robot to station
Press together with On/Off (5 sec)
for WLAN connection

Switch mode

Press to switch cleaning mode:
dry cleaning or
wet & dry cleaning

Lights

Device boot/ Firmware update

LED On/Off & Home: white breathing
LED stripe: white breathing

Network connection

LED On/Off & Home: blue breathing
LED stripe: off

Robot standby

LED On/Off & Home: off
LED stripe: off

Robot charging

LED On/Off & Home: green breathing
LED stripe: off

Robot cleaning

LED On/Off & Home: yellow (dry cleaning)
or blue (wet & dry cleaning)
LED stripe: yellow (dry cleaning)
or blue (wet & dry cleaning)

Error

LED On/Off & Home: red blinking
LED stripe: red blinking

Kärcher Indoor Robots App



Scan for details



www.kaercher.com/int/home-garden/robot-vacuums-and-mops.html

Operating Instructions



KÄRCHER

RVF 7 QUICKSTART GUIDE



5.979-756.0 (02/26)

100 mm

100 mm













100 mm

300 mm

210 mm

INSIDE

Install device





- 
Consider correct positioning
- 
Attach side brushes
- 
Place the robot in charging station
- 
Download Kärcher Indoor Robots App
- 
Add robot
- 
Scan QR code
- 
Press On/Off and Home to connect to WLAN
- 
Network configuration
- 
Device is now ready for use
- 
Start mapping
- 
Follow the configuration steps in the App
- 
Device is now ready to clean

Start cleaning

Dry cleaning













- 
Select cleaning mode
- 
Start cleaning

Wet and dry cleaning

- 
Select cleaning mode
- 
Detach fresh water tank
- 
Fill fresh water container with water and detergent (5 caps = 10ml)
- 
Add FoamStop (optional, if needed) (2 caps = 4ml)
- 
Attach fresh water tank
- 
Start cleaning

Cleaning of device



- 
Detach dirt water tank
- 
Clean dirt water tank
- 
Clean sensors
- 
Attach dirt water tank
- 
Detach dry dirt box
- 
Empty dry dirt box and reattach
- 
Remove roller unit
- 
Detach and wash roller in washing machine
- 
Clean roller unit
- 
Attach roller unit
- 
Wipe all sensors
- 
Wipe LIDAR sensor

210 mm

100 mm

100 mm

100 mm

300 mm